Mmicrosonic



Instruction manual vnp-Ultrasonic Sensors with one switched output

vnp-25/D/TC vnp-35/D/TC vnp-130/D/TC vnp-340/D/TC vnp-600/D/TC

Product description

Set the relative detect point numerically using LED-display...

- The vnp-sensor with one switched output measures the distance to an object within the detection zone contactless. Depending on the adjusted detect points the switched output is set.
- The actual detect point arise from a virtual origin set with the Teach-in procedure and an offset that is set numerically using two push-buttons and a three-digit LED-display (TouchControl). As an additional feature the virtual origin can be shifted contineousely by connecting the control input line »Sync/Com« at pin 5 of the sensor connector to +U_R.
- Light emitting diodes (three-colour LEDs) indicate the switching status.
- The output functions are changeable from NOC to NCC.
- Useful additional functions are set in the Add-on-menu ■ The measured distance value can be
- displayed relatively in relation to the virtual origin (see Add-on-menu).
- Using the LinkControl adapter (optional accessory) all TouchControl and additional sensor parameter settings may be made by a Windows-Software.

Important instructions for assembly and application

All employee and plant safety-relevant measures must be taken prior to assembly, start-up, or maintenance work (see operation manual for the entire plant and the operator instruction of the plant).

The sensors are not considered as safety equipment and may not be used to ensure human or machine safety!

The vnp-sensors indicate a blind zone, in which the distance cannot be measured. The operating range indicates the distance of the sensor that can be applied with normal reflectors with sufficient function reserve. When using good reflectors, such as a calm water surface, the sensor can also be used up to its maximum range. Objects that strongly absorb (e.g. plastic foam) or diffusely reflect sound (e.g. pebble stones) can also reduce the defined operating range.

Synchronisation

If the assembly distances shown in Fig.1 for two or more sensors are exceeded the integrated synchronisation should be used. Connect Sync/Com-channels (pin 5 at the units receptable) of all sensors (10 maximum).




Fig. 1: Assembly distances, indicating synchronisation/multiplex

Multiplex mode

The Add-on-menu allows to assign an individual address »01« to »10« to each sensor connected via the »Sync/Com« line (Pin5). The sensors perform the ultrasonic measurement sequentially from low to high address. Therefore any influence between the sensors is rejected.

The address »00« is reserved to synchronisation mode and deactivates the multiplex mode. (To use synchronised mode all sensors must be set to address »00«.)

Assembly instructions

Assemble the sensor at the installation lo-




Fig. 2: Pin assignment with view onto sensor plug and colour coding of the microsonic connection cable

Start-up

vnp-sensors are delivered factory made with the following settings:

- Switched output on NOC
- Offset at 10 cm
- Measurement range set to maximum ran-

Set the parameters of the sensor manually to adjust the relative detect point (offset).

- Plug in the connector cable to the M 12

 The offset can be programmed in the range of ± 99 cm around the teachable
 - For an offset less than 10 cm the programmable resolution is 1 mm.




Fig. 3: TouchControl

By connecting the control input line »Sync/ Com« at pin 5 for 3 seconds to + UB the virtual origin is set to the actually measured distance. This has to be done in normal opera-

vnp-sensors work maintenance free. Small amounts of dirt on the surface do not influence function. Thick layers of dirt and cakedon dirt affect sensor function and therefore must be removed.

- vnp-sensors have internal temperature compensation. Because the sensors heat up on their own, the temperature compensation reaches its optimum working point after approx. 30 minutes of operati-
- During normal mode operation, a vellow LED D2 signals that the switched output has connected.
- During normal mode operation, the measured distance value is displayed on the LED-indicator in mm (up to 999 mm) or cm (from 100 cm). Scale switches automatically and is indicated by a point on top of the digits.
- During Teach-in mode, the hysteresis loop is set back to factory settings.
- If no objects are placed within the detection zone the LED-indicator shows »- - -«.
- If no push-buttons are pressed for 20 seconds during parameter setting mode the made changes are stored and the sensor returns to normal mode operation.
- You can lock the key pad to provide inputs, see »Key lock and factory setting«.
- You can reset the factory settings at any time, see »Key lock and factory setting«.

Show parameters

Tapping push-button T1 shortly during normal mode operation shows »PAr« on the LED-display. Each time you tap push-button T1 the actual settings of the switched outputs are shown.

