

Operating Instructions

Ultrasonic proximity switch with one switched output

pico+15/F pico+25/F pico+35/F pico+100/F pico+15/WK/F pico+25/WK/F pico+35/WK/F pico+100/WK/F

Product description

The pico+ sensor offers a non-contact measurement of the distance to an object which must be positioned within the sensor's detection zone. The switched output is set conditional upon the adjusted detect distance.

Via the Teach-in procedure, the detect distance and operating mode can be adjusted. Two LEDs indicate operation and the state of the switched output.

IO-Link

The pico+ sensors are IO-Link-capable in accordance with IO-Link specification V1.0.

Safety instructions

- Read the operating instructions prior to start-up.
- Connection, installation and adjustments may only be carried out by qualified staff.
- No safety component in accordance with the EU Machine Directive

Use for intended purpose only pico+ultrasonic sensors are used for non-contact detection of objects.

Installation

- Mount the sensor at the place of fitting.
- Connect a connection cable to the M12 device plug.

2 • 1 • 3 • 5 • 4	1	colour
1	+U _B	brown
3	-U _B	blue
4	F	black
2	-	white
5	Com	grey

Fig. 1: Pin assignment with view onto sensor plug and colour coding of the microsonic connection cables

Start-up

- Connect the power supply.
- Carry out sensor adjustment in accordance with the diagram.

Factory setting

- Detect point operation
- Switched output on NOC
- Detect distance at operating range
- Multi-function input »Com« set to »Teach-in«
- Filter at F01
- Filter strength at P00

Operating modes

Three operating modes are available for the switched output:

- Operation with one detect point The switched output is set when the object falls below the set detect point.
- Window mode

The switched output is set when the object is within the set window.

■ Two-way reflective barrier The switched output is set when the object is between sensor and fixed reflector.

Synchronisation

If under multiple sensor operation the assembly distance falls below the values shown in Fig. 2, the internal synchronisation should be used. For this purpose set the switched outputs of all sensors in accordance with the diagram "Sensor adjustment with the Teach-in procedure". Then change the multi-function output "Com" to "synchronisation" (see "Further settings"). Finally interconnect each pin 5 of the sensors to be synchronised.





Fig. 2: Assembly distances


Maintenance


microsonic sensors are maintenancefree. In case of excess caked-on dirt we recommend cleaning the white sensor surface


Notes

- The sensors of the pico+ family have a blind zone, within which a distance measurement is not poscible.
- Every time the power supply is switched on, the sensor detects its actual operating temperature and transmits it to the internal temperature compensation. The adjusted value is taken over after 120 seconds.
- In the normal operating mode, an illuminated yellow LED signals that the switched output is switched through.
- The pico+sensors have a push-pull switched output.
- In the »Two-way reflective barrier« operating mode, the object has to










accuracy ±1 % (temperature drift internally compensated) operating voltage U_B 10 - 30 V DC, reverse polarity protection (Class 2) voltage ripple ±10 % housing: brass sleeve, nickel-plated, plastic parts; PBT; ultrasonic transducer: polyurethane foam, epoxy resin with glass content type of connection 5-pin M12 circular plug controls | Teach-in via pin 5 (Com) indicators : LED green (operation) LED yellow (state of output) programmable Teach-in, LinkControl synchronisation internal synchronisation up to 10 sensors operating temperature : -25°C to +70°C storage temperature -40°C to +85°C switched output | Push-Pull, U_B-3 V, -U_B+3 V, I_{max} = 100 mA switchable NOC/NCC, short-circuit-proof

switching hysteresis 1) 2 mm switching frequency 1) 25 Hz response time 1) 32 ms time delay before availability 1) < 300 ms norm conformity EN 60947-5-2

order no. directly radiating pico+15/F weight 30 g

detection zones


order no. angular head | pico+15/WK/F weight 35 g




LED

SW24~

pico+25...





be within the range of 0-85 % of the set distance.

- In the »Set detect point method A« Teach-in procedure the actual distance to the object is taught to the sensor as the detect point. If the object moves towards the sensor (e.g. with level control) then the taught distance is the level at which the sensor has to switch the output.
- If the object to be scanned moves into the detection area from the side, the »Set detect point +8 % method B« Teach-in procedure should be used. In this way the switching distance is set 8 % further than the actual measured distance to the object. This ensures a reliable switching distance even if the height of the objects varies slightly.




Fig. 4: Setting the detect point for different directions of movement of the object

- If synchronization is activated the Teach-in is disabled (see »Further settings«).
- The sensor can be reset to its factory setting (see »Further settings«).
- Using the LinkControl adapter (optional accessory) and the LinkControl software for Windows, all Teach-in and additional sensor parameter settings can be optionally undertaken.



2014/30/EU



Enclosure Type 1 For use only in industrial machinery NFPA 79 applications.

The proximity switches shall be used with a Listed (CYJV/7) cable/connector assembly rated minimum 32 Vdc, minimum 290 mA, in the final installation

IO-Link mode

The pico+ sensors are IO-Link-capable in accordance with IO-Link specification V1.0.

Pointer

- In IO-Link mode Teach-in, Link-Control and synchronization via pin 5 are not available.
- In IO-Link mode pin 5 must not be connected to any potential.
- For current information about IO-Link please contact the microsonic sales department.

Synchronisation in IO-Link mode

In IO-Link mode each sensor is synchronized on the protocol of the IO-Link master.

In multiple sensor operation the sensors are synchronous if the master protocols are synchronous.

Process data

The pico+ cyclically transmits the measured distance value with a resolution of 0,1 mm and the state of

the switched output.

Service data

The following sensor parameters may be set via IO-Link interface using the IO-Link device description (IODD).

Detect point 1

The switched output is activated when the distance to an object is under that of the present detect point.

Return detect point 1

The switched output is reactivated when the distance to an object is greater than the present return detect point (detect point + hysteresis).

Pointer

■ The return detect point 1 must always be greater than the detect point 1.

Detect point 2, return detect point 2

By programming these two detect distances the window mode is activated.

Pointer

■ The return detect point 2 must always be smaller than the detect point 2.

NOC/NCC operation

The NCC or NOC output function can be present for the switched output.

Measurement filter

pico+ ultrasonic sensors provide for a choice of 3 filter settings:

■ F00

No filter, each ultrasonic measurement acts in an unfiltered manner on the output.

■ F01

Standard filter, on the object continuously approaching the sensor, the ongoing interval is immediately taken on and the output correspondingly activated. The effect of the object abruptly moving away from the sensor is for the existing distance to be saved for a retaining time dependent on the filter strength and for the switched

output state to be maintained.

■ F02

Average value filter, forms the arithmetic mean across a number of measurements. The output is activated in keeping with the average value. The number of measurements, from which the average value is formed, depends on the selected filter strength.

Filter strength

A filter strength between 0 – weak filter effect – and 9 – pronounced filter effect – can be selected for each measurement filter.

Foreground suppression

Spurious reflections, caused by objects in the foreground of the sensor may be blocked out by the foreground suppression.

Pointer

■ Check that the object in the foreground does not cause multiple reflections. ■ The object in the foreground must not cover the sensor in a way that the detection zone is influenced.

System commands

With 4 system commands the following settings may be carried out:

- Teach-in detect point method A.
- Teach-in detect point method B.
- Teach-in two way reflective barrier.
- Reset sensor to factory settings.

Pointer

To achieve the maximum resolution the Master Cycle Time has to comply with the following requirements:

- Min Cycle Time ≤ Master Cycle Time ≤ Min Cycle Time + 1.2 ms.
- If this condition can not be full-filled, sporadic discontinuities of the measurement value can occur. In this case the Master Cycle Time has to be increased in 400 µs steps until the discontinuities of the measurement disappear.

Pointer

■ If the pico+ sensor was set using Teach-in or LinkControl it is recommended to reset the sensor to the factory setting prior to using it in IO-Link mode (s. »Further settings«).

IODD file

The latest IODD file you will find on the internet under www.microsonic.de/en/IODD.

For further informations on IO-Link see www.io-link.com.

IO-Link data																
	D.	•11111	111	pico+15	D:	ш	1111	pico+25	D.	0111		pico+35	D:	01111]]	p	ico+100
physical layer																
SIO mode support	yes				yes				yes				yes			
min cycle time	8.4 ms	S			8.4 m	5			16 ms				20.4 r	กร		
baud rate	COM 2	COM 2 (38.400 Bd)			COM	COM 2 (38.400 Bd)		COM 2 (38.400 Bd)			COM 2 (38.400 Bd)					
format of process data	16 Bit,	R, UNI16	;		16 Bit,	16 Bit, R, UNI16		16 Bit, R, UNI16			16 Bit	16 Bit, R, UNI16				
content of process data	Bit 0: 9	state of sv	vitched	output;	Bit 0: :	Bit 0: state of switched output;		Bit 0: state of switched output;		Bit 0: state of switched output;						
					Bit 1-1	Bit 1-15: distance value with 0,1 mm resolution		Bit 1-15: distance value with 0,1 mm resolution		Bit 1-15: distance value with 0,1 mm resolution						
service data IO-Link specific	index		access	value	index		access	value	index		access	value	index	ac	cess	value
Vendor name	0x10		R	microsonic GmbH	0x10		R	microsonic GmbH	0x10		R	microsonic GmbH	0x10	R	, j	microsonic GmbH
Vendor text	0x11		R	www.microsonic.de	0x11		R	www.microsonic.de	0x11		R	www.microsonic.de	0x11	R		www.microsonic.de
Product name	0x12		R	pico+	0x12		R	pico+	0x12		R	pico+	0x12	R		pico+
Product ID	0X13		R	15/F;15/WK/F	0X13			25/F;25/WK/F	0X13		R	35/F;35/WK/F	0X13	R	- ;	100/F;100/WK/F
Product text	0x14		R	Ultraschall-Sensor	0x14		R	Ultraschall-Sensor	0x14		R	Ultraschall-Sensor	0x14	R		Ultraschall-Sensor
				'				'								
service data sensor specific	index	format	access	range (dez)	index	format	access	range (dez)	index	format	access	range (dez)	index	format ac	cess	range (dez)
detect point 1	0x40	UINT16	R/W	306-3,609 (21-248 mm) 1)	0x40	UINT16	R/W	436-5,065 (30 - 348 mm) 1)				946-8,704 (65 - 598 mm) 1)	0x40	UINT16 RA	Ν	1,747-18,892 (120 - 1,298 mm) 1)
return detect point 1	0x41	UINT16	R/W	320-3,624 (22-249 mm) 1)	0x41	UINT16	R/W	451-5,080 (31 - 349 mm) 1)	0x41	UINT16		961-8,718 (66 - 599 mm) 1)	0x41	UINT16 RA	Ν	1,761-18,907 (121 - 1,299 mm) 1)
detect point 2	0x47	UINT16	R/W	335-65,512 (23 - 250 mm) 1)	0x47	UINT16		466-65,512 (32 - 350 mm) 1)	0x47	UINT16		975-65,512 (67 - 600 mm) 1)	0x47	UINT16 R/V		1,776-65,512 (122 - 1,300 mm) 1)
				> 3,638: window mode deactivated				> 5,094: window mode deactivated				> 8,733: window mode deactivated				> 18,922: window mode deactivated
return detect point 2	0x48	UINT16	R/W	320-65,512 (22 - 250 mm) 1)	0x48	UINT16	R/W	451-65,512 (31 - 349 mm) 1)	0x48	UINT16		961-65,512 (66 - 599 mm) 1)	0x48	UINT16 R/V	V	1,761-65,512 (121 - 1,299 mm) 1)
				> 3.638: window mode deactivated				> 5,094: window mode deactivated				> 8,733: window mode deactivated				> 18,922: window mode deactivated
switching mode				00: NCC, 02: NOC		UINT8		00: NCC, 02: NOC		UINT8		00: NCC, 02: NOC		UINT8 R/V		00: NCC, 02: NOC
		UINT8		00-02: F00 - F02		UINT8		00-02: F00 - F02		UINT8		00-02: F00 - F02		UINT8 R/V		00-02: F00 - F02
filter strength				00-09: P00 - P09		UINT8		00-09: P00 - P09		UINT8		00-09: P00 - P09		UINT8 R/V		00-09: P00 - P09
foreground suppression				0-1,878 (0-129 mm) 1)		UINT16		0-3,246 (0-223 mm) 1)		UINT16		0-4,236 (0-291 mm) 1)		UINT16 R/V		0-12,969 (0-891 mm) 1)
Teach-in via Pin 5 in SIO mode	0x4A	: UINT8	R/W	00: deactivated, 16: activated	0x4A	UINT8	: R/W	00: deactivated, 16: activated	0x4A	UINT8	R/W	00: deactivated, 16: activated	0x4A	UINT8 R/V	V	00: deactivated, 16: activated
												,				
system commands				value	index		access		index		access		index			value
Teach-in detect point – method A				161	0x02			161	0x02			161	0x02	W		161
Teach-in detect point – method B			W	162	0x02			162	0x02			162	0x02	W		162
Teach-in two way reflective barrier				164	0x02			164	0x02			164	0x02	W		164
reset to factory settings			W	168	0x02			168	0x02			168	0x02	W	1	168
1) Distance values, e.g. detect points, are given as multiple of the internal resolution of the measurement value = 0,069 mm (example: 320 \u22012 22 mm). The values in the table are decimal.																