# ωιςιογουις **Product description**



**Operating Manual** 

Ultrasonic proximity switch with one switched output

- nano-15/CD nano-15/CE nano-24/CD nano-24/CE
- Sensor adjustment with Teach-in procedure

dance with the EU Machine Direc-The nano sensor offers a non-contact tive. measurement of the distance to an object which must be positioned

within the sensor's detection zone.

The switched output is set condi-

tional upon the adjusted detect dis-

Via the Teach-in procedure, the de-

tect distance and operating mode

Read the operating instructions

adjustment works should be car-

ried out by expert personnel only.

■ No safety Component in accor-

■ Connection, installation

the switched output.

prior to start-up.

Safety notes

tance.

Use for intended purpose only

nano ultrasonic sensors are used for non-contact detection of objects.

### Installation

- Mount the sensor at the installation site.
- Connect a connection cable to the M12 device plug.

2 for two or more sensors should not be fallen below in order to avoid mutual interference.

### Start-up

and

- Connect the power supply.
- Carry out sensor adjustment in accordance with the diagram.



Fig. 1: Pin assignment with view onto sensor plug and colour coding of the



Fig.2: Assembly distances

### Factory setting

- Detect point operation.
- Switched output on NOC.

Detect distance at operating range.

### **Operating modes**

- Three operating modes are available for the switched output:
- Operation with one detect point The switched output is set when the object falls below the set detect point.
- Window mode

The switched output is set when the object is within the set window. Two-way reflective barrier

The switched output is set when the object is between sensor and fixed reflector.



Maintenance

microsonic sensors are maintenancefree. In case of excess caked-on dirt we recommend cleaning the white sensor surface.

## Notes

- Every time the power supply is switched on, the sensor detects its actual operating temperature and transmits it to the internal temperature compensation. The adjusted value is taken over after 45 seconds.
- If the sensor was switched off for at least 30 minutes and after power on the switched output is not set for 30 minutes a new adjustment of the internal temperature compensation to the actual mounting conditions takes place.
- The sensors of the nano family have a blind zone. Within this zone a distance measurement is not possible.
- In the normal operating mode, an illuminated yellow LED signals that the switched output is switched through.
- In the »Two-way reflective barrier« operating mode, the object has to be within the range of 0-85 % of the set distance.
- In the »Set detect point method A« Teach-in procedure the actual distance to the object is taught to the sensor as the detect point. If the object moves towards the sensor (e.g. with level control) then the taught distance is the level at which the sensor has to switch the output.
- If the object to be scanned moves into the detection area from the side, the »Set detect point+8 % method B« Teach-in procedure should be used. In this way the switching distance is set 8 % further than the actual measured distance to the object. This ensures a reliable switching distance even if the height of the objects varies slightly.

# microsonic connection cables

can be adjusted. One 2-colour LED indicates operation and the state of The assembly distances shown in fig.

### Technical data





*Fig. 4:* Setting the detect point for different directions of movement of the object

 The sensor can be reset to its factory setting (see »Further settings«).





2004/108/EC